



Model 306 Curfew Clock Instructions

This Curfew Clock is operated by three buttons: **MODE**, **SET** and **START/STOP**. To power up, connect the supplied 12 volt regulated direct current (DC) power adapter (center positive) to unit and follow the instructions for operation.

When the Curfew Clock is first plugged-in, the horn will sound and all LED's will flash 3 times; this is the power-up indication procedure. After this, the display will blank out completely and then each of the 4 digits will successively light until all LED's are illuminated. This will continue for several seconds, and then all LED's will shut off, and then the time of day will be displayed. If the time of day display is not selected (refer to the following instructions), then just 2 LED's in the bottom middle of the panel will be displayed. This indicates that the Curfew Clock is awaiting user intervention.

Set Curfew Time: MINUTES

- Press **MODE**, until "C: xx" is displayed.
- Press **SET** to increment the curfew time minutes setting (0 to 59 minutes).
- Press **START/STOP** to decrement the

Set Curfew Time: HOURS

- Press **MODE**, until "C:xx " is displayed.
- Press **SET** to increment the curfew time hours (0 to 9 hours).
- Press **MODE** to Confirm

<p>curfew time minutes setting.</p> <ul style="list-style-type: none"> • Press MODE to Confirm <p>Set Time-of-Day DISPLAY MODE</p> <ul style="list-style-type: none"> • Press MODE until “td:xx” is displayed. • Press SET to toggle between “on” and “oF”. “on” indicates that time-of-day will be displayed when the curfew clock is idle. “oF” means that only 2 LED’s in the middle center of the display will be illuminated when the curfew clock is idle. • Press MODE to confirm. 	<p>NOTE: Press START/STOP to immediately start counting down the curfew time setting (Quick Start Method). The other set-up menus will be bypassed.</p> <p>Set Time-of-Day: MINUTES</p> <ul style="list-style-type: none"> • Press MODE until “ :xx” is displayed • Press SET to increment time-of-day minutes. • Press START/STOP to decrement time-of-day minutes. • Press MODE to confirm.
<p>Set Time-of-Day: HOURS</p> <ul style="list-style-type: none"> • Press MODE until “xx: ” is displayed. • Press SET to increment the hour setting. • Press START/STOP to decrement the Hour setting. • Press MODE to confirm. 	<p>Set Time-of-Day FORMAT</p> <ul style="list-style-type: none"> • Press MODE until “xx: H” is displayed • Press SET to toggle between “12h” (12 hour) and “24h” (24 hour) time format. • Press MODE to confirm.
<p>Set BRIGHTNESS</p> <ul style="list-style-type: none"> • Press MODE until “br: x” is displayed • Press SET to increment the LED brightness setting (0 to 6). • Press START/STOP to decrement the brightness setting • Press MODE to confirm 	<p>READY Mode</p> <ul style="list-style-type: none"> • Press MODE until... <ol style="list-style-type: none"> 1. Two small dots are illuminated in the middle of the display, or, 2. Until the time-of-day is displayed.

Starting the Curfew Clock

1. From Ready-Set Mode, press **START/STOP** to begin counting down, or,
2. From the setup menu, Set Curfew Time: HOURS press **START/STOP**.

Press **MODE** at any time during the countdown session and the session will be cancelled and the operation will return to the **Ready-Set Mode**. Either two dots will appear in the middle bottom of the display, or the time-of-day will be displayed (depending on whether Time-of-Day Display Mode was set for “oF” (off) or “on”).

Press **START/STOP** at any point in the fitness session to halt the session. Press **START/STOP** again to resume the session at the exact place it was halted.

Wireless Remote Instructions: (optional)

The wireless remote has three buttons and will operate the same as the buttons on the clock. The buttons are labeled as follows:

- (1) **MODE**
- (2) **SET**
- (3) **START/STOP**

Battery Installation (Battery Type: 23A, 12VDC)

Remove back of remote with a #1 Phillips screw driver. Once the back of the remote is off, remove battery carefully. Replace battery with new **23A, 12V** battery, **taking note of the polarity markings found on the inside of the back cover of the remote**).

Mounting Instructions

For wall mounting installation: Place two # 10, 1 ¼” long screws* (included) in wall 16” apart (16” center to center). Ensure these screws are at the same height for level.

For table mounting installation: Use the # 8, ½” screws (included) to attach the table stand (included) to the rear of the timer. Once the stand is secure, the timer will stand on its own.

*May use other size screws as long as it is at least a #10 screw. The length may vary depending on the installation point.