



MODEL 606 CASINO CLOCK – INSTRUCTIONS

The Nik Design Countdown Clock is operated by three buttons: **MODE (Black)**, **SET (White)** and **START / STOP (Red)**.

Set up time: Default value is 20:00 min

<p>Set Minutes:</p> <ul style="list-style-type: none">• Press MODE, until only minutes are displayed.• Press SET to increase to desired minute.• Press START / STOP to decrease.• Press MODE to confirm selection.	<p>Set Seconds:</p> <ul style="list-style-type: none">• Press MODE until only seconds are displayed.• Press SET to increase to desired seconds.• Press START / STOP to decrease to desired seconds.• Press MODE to confirm selection.
<p>Set Brightness:</p> <ul style="list-style-type: none">• Press MODE until "br" is displayed.• Press SET to increase to desired brightness• (0 to 6, 0 being dim and 6 being brightest).• Press MODE to confirm selection. <p>*Default value is "br3".</p>	<p>START / STOP:</p> <ul style="list-style-type: none">• Press START / STOP to start or stop the countdown clock.
<p>Wireless Remote Instructions:</p> <p>The wireless remote has three buttons and will operate the same as the normal click. The buttons are labeled as follows:</p> <ol style="list-style-type: none">1) MODE2) SET3) START / STOP	<p>RESET:</p> <p>If you wish to reset the time, press the MODE button while the clock is counting down. This will reset the clock back to the original time.</p>